

# Monolever Wheel Adapter Kit

**4201431** (for use with RS202 Computerised Wheel Balancer)

## Kit contents:

Large Flange (Part 1)

Centralising Cup



Wheel rings - Ø

72mm

65mm

62mm

61mm

55mm

54mm



1. Fit large flange onto balancing shaft



2. add wheel specific ring to flange



3. Fit wheel



4. Locate on wheel specific ring



5. Add centralising cup



6. Fit spacers as required then add lock nut...balance wheel.



The main flange mounting is Ø43mm which will fit earlier Ducatis.

Models identified to date include:

Ø54mm - DUCATI 1098

Ø55mm - DUCATI 916 / 996 / 998

Ø61mm - Triumph 595 / 955i / Speed Triple

Ø62mm - BMW various models

Ø65mm - Triumph Explorer

Ø72mm - BMW K1600